

BRIMORBY Casings

Water Proof (WPL) 1000
Construction



1. Excavate to required depth and diameter.

2. Place and compact bedding.

3. Place and compact filter layer.

4. Place and compact casing.

5. Place and compact topsoil.



6. Place and compact topsoil.

7. Place and compact topsoil.

8. Place and compact topsoil.

